

# Union body Metal Housing Dual band RFID IP Controller with Piezo Touch Key

# AR-363-E



## 1. Product Features

- Durable, Weather & Corrosion Resistance
- IP66, good dust and liquid resistance

- Fully Sealed Protection
- Seamlessly Support SOYAL Cascade Structure Expandable User Capacity to More than 10,000 Users

## 2. Application

- SOYAL Access Control and Attendance
  - SOYAL Access Related Function

Access Control Basic Terminology such as multi-door, single-door, all-in one control and separate control

## 3. How to Order





## Table of Contents

01. Command List	01
02. Compound Command Function List	02
03. Adding and Deleting Tag	04
04. Programming	04
05. Restoring Factory Settings	07
06. Firmware Upgrade	08
07. IP Setting	80
08. Notice	09
09. Connector Table	10
10. Wiring Diagram	10
11. Installation	12
12. Dimension(mm)	12
13. Numeric Keypad Press Method	12
14. Contents	12



_	
01	Command List

Function	Command	Exposition		
Entering programming mode	* PPPPP #	PPPPPP: Master Code, (Default value: 123456)		
Exiting programming mode	<b>*</b> #			
into arming status.	**#	Including AR-363-E, WG Reader		
Enabling each device into arming status.	* * U #	U=Enable target unit (0=AR-725-E , 1=WG Reader)		
		NNN=Node ID,(001~254)		
Node ID setting	00 * NNN * MMM * AAA #	MMM=AR-363-E Door Number,(001~255)		
		AAA=WG Reader Door Number,(001~255)		
		CCCCCCCCCCC = 192168001127		
		If set to 000 000 000 000 will enable DHCP otherwise		
IP Address assign (Must power reset)		will disable DHCP		
	01 * 1 * 255255255000 #	Netmask		
	01 * 2 * 192168001254 #	Gateway assign		
Deer relevative esting		U=Enable target unit (U=AR-363-E, 1=WG Reader)		
Door relay time setting		111 = Door relay time, 000 (Output constantity)		
		TTT = Alarm relay time : 000 (Output constantly)		
Alarm relay time setting	03 <b>*</b> TTT <i>#</i>	001 - 600 = 1 - 600 Sec		
Mode setting	04 * M #	M=4 (Mode 4) ; M=8 (Mode 8)		
Arming delay time setting	05 * TTT #	Base on second range 001~255		
Alarm delay time setting	06 * TTT #	Base on second range: 001~255		
		SSSSS-EEEE=00000~15999		
Master card setting	07 * SSSSS * EEEEE #	SSSSS= starting user address; EEEEE= ending user address		
		M=AR-363-E; W=WG Reader (0=disable; 1=enable)		
		NN= <mark>16 sets of au</mark> to-open zone (Range: 00~15)		
	08 * MW * NN * HHMMbbmm *	HHMMhhmm=staring time to ending time		
Auto-open zone setting	7123456H #	(e. <mark>g.: 08301200=08:3</mark> 0 to 12:00)		
		7123456: 7 days of week -Sun/Mon/Tue/Wed/Thu/Fri/Sat		
		(Input value: 0=disable; 1=enable)		
		H: Holiday (Input value: 0=disable; 1=enable)		
Master code settings	09 * PPPPPRRRRR #	RRRRR= Repeat the new master code		
	Suspend : 10 * SSSSS * EEEEE #	*:Suspend 9:Delete		
Suspend or delete tags	Delete : 10 * SSSSS 9 EEEEE #	SSSSS= starting user address; EEEEE= ending user address		
Recover tag	11 * SSSSS * EEEEE #	SSSSS= starting user address; EEEEE= ending user address		
Setting up Card or PIN mode by user addressModify the		UUUUU= user address;		
user's access PIN according to the user's address, and	12 * UUUUU * PPPP~PPPPPPP #	PPPP~PPPPPP=4digit (default)~8-digit individual PWD		
change the control mode to Card of PIN		(Access mode: Card or PIN)		
Setting up Card and PIN mode by user address	13 * UUUUU * PPPP~PPPPPPP #			
		Base on 1ms, range:1~255, default value=10,		
		Input 0= Timeless		
Duress code setting		PPPP=4-digit PWD (0001-9999) ; Default value : 0000		
		and the default value is set as 0000 already.		
Card number modification		UUUUU=user address		
		SSSSS=5 digit site code ; CCCCC=5 digit card code		
Arming PWD setting	17 * PPPP #	PPPP=4-digit PWD (0001-9999)		
		Default value : 1234		
Enabling or Disabling into arming status	Card+NNNN #	II = Enable target unit (0=AR-363-E = 1=WG Reader)		
Enabling or Disabling each device into arming status.	Card+NNNN * U #			
Enabling all device into arming status.	Card+NNNN * * #			
Disabling all device into arming status.	Card+NNNN * # 9			
Deer open weiting time	10 ± 11 ± TTT #	U=Enable target unit (0=AR-363-E , 1=WG Reader)		
		TTT=Door open waiting time:001~600;default value:15 sec.		
Add card by presenting	19 * UUUUU * 00000 #	UUUUU=user address		
		QQQQ=Card quantity(00001=Continuously inducting)		
Reader additional setting	20 * U * DDD #	U=Enable target unit (U=AR-363-E, 1=WG Reader)		
1				

Illuminated Touch-panel

V250108

Function	Command	Exposition							
Lift control setting: multi-doors	21 * UUUUU *G *LLLLLLL #	UUUUU=user address : G=4 sets of lift control(0~3); LLLLLLL=8 assigned floor (F=0: Disable, 1: Enable)							
Add/Delete tag by presenting (M6 only)	22 * N #	N=0(Delete tag); N=1(Add tag)							
		MMM=Node ID of lift controller							
AR-401RO16/ AR-401RO16B relay time setting	23 * MMM * TTT #	TTT= relay time: 000~600=1~600 sec.							
Factory setting	24 * 0 or 1 *??? #	0 or 1=Enable target unit (0=Main Controller Parameter Setting , 1=WG Input Port Parameter Setting) ???: Function default value							
Real time clock setting	25 * YYMMDDHHMMSS #	YYMMDDHHmmSS: Year/Month/Day/Hour/Min./Sec.							
Anti-pass-back (Enable user)	26 * SSSSS * EEEEE * P #	SSSSS= starting user address; EEEEE= ending user address P=0=Enable; P=1=Disable; P=2=Initial							
Lift control setting: single door	27 * UUUUU * LL #	UUUUU=user address; LL: Floor number(01~64 floor)							
Duress Function and Arming output setting	28 * ??? #	Arming output and Duress function: ???= 008 (default value)							
Delete all tag	29 * 29 * #								
Same tag reading interval time	31 <b>*</b> TTTT <b>#</b>	Base on 10ms, range from 10 to 6000							
Auto ring the clock alarm schedule	32 * SS * HHMMTT * 7123456H #	SS= 16 sets auto alarm schedule, range 0~15 HHMM= HH:MM (ex. 0830: Ring bell at 08:30) TT=Period of time to ring bell (Base on second, range 01~99 sec.) 7123456: 7 days of week -Sun/Mon/Tue/Wed/Thu/Fri/Sat (Input value: 0=disable; 1=enable) H: Holiday (Input value: 0=disable; 1=enable)							
Holiday Setting	35 <b>*</b> ) MMDD <b>*</b> F #)	MM= Month of year (01=Jan10=Oct.) DD= Date of month (01=1st day of month) F= 0:Delete ; 1: Add							
Enabling or Disabling into Full Access status	36 ★ MW #	M=AR-363-E; W=WG Reader (0=disable; 1=enable)							
RS485 port function setting (Needs to be restarted after setting)	37 <b>*</b> AB #	A=0:AR401RO         B=0: 9600(default value)           1:Host (default value)         1: 19200           2:LED Panel         2: 38400           3:Printer         3: 57600							
TTL port BAUD setting	38 * DDD #	DDD: 001=4800 bps DDD: 129=19200 bps							
Change WG bits output format	41 * n #	n: 0=WG26 ; n: 1=WG34							
PIN & UID Length setting	42 * m * n #	m=PIN code Length 4~8 Digit / n = UID Length 2~8 Digit							

## 02. Compound Command Function List

#### Weighted Value Manual :

#### Step 1:

Select the "Function" that you need for each Compound Command category (20 \*, 24 \*, etc)

#### Step 3:

Substract the "Value" of each Option with Selection. Function = [0(deactive)\*Value] ; [1(activate)\*Value]

#### Step 2:

"Selection" of the function that you need is either have 0 or 1 value.

#### Step 4:

Add up all of the Function per Compound Command (20 \* , 24 \* ,etc)

20 ± 0 ± ??? #) (Main Controller Parameter Setting)									
20 * 1 * ??? # (WG Input Port Parameter Setting)									
Function	Opt	ion	Value	Bit	Application				
Entry and Exit Access is recorded on Duty Report	<b>※0: Yes</b>	1: No	001	0	Networking				
Activate close door automatically lock (Auto-Relock)	isable ≫0: Disable	1: Enable	002	1	Networking/Stand-Alone				
Auto Open	※0: Disable	1: Enable	004	2	Networking/Stand-Alone				
When Access Mode is "Card and PIN", Readers can skip pressing PIN code	%0: Disable	1: Enable	008	3	Networking/Stand-Alone				
Exit by Push Button	0: Disable	%1: Enable	016	4	Networking/Stand-Alone				
Enable force Open trigger alarm	※0: Disable	1: Enable	032	5	Networking				
Entry/Exit Reader	i tit 80: €xit	1: Entry	064	6	Networking				
Anti-pass-back	%0: Disable	1: Enable	128	7	Networking				



24 * 0 * ??? #) (Main Controller Parameter Setting)									
24 * 1 * ??? # (WG Input Port Parameter Setting) *Default Value									
Function	Option		Value	Bit	Application				
Enable Egress Beep Sounds	0: Disable	※1: Enable	001	0	Networking/Stand-Alone				
			002	1					
			004	2					
Arm/Disarm Zone(Zone: 62)	%0: Enable	1: Disable	008	3	Networking/Stand-Alone				
Reader and controller share the same door relay (only for WG reader)	0: Disable	※1: Enable	016	4	Networking/Stand-Alone				
©Enable swipe any tags to release door open	%0: Disable	1: Enable	032	5	Networking/Stand-Alone				
Stop alarm by pressing push button or closing the door	%0: Disable (must swipe valid card)	1: Enable	064	6	Networking/Stand-Alone				
Enter auto open time zone without presenting valid card	%0: Disable (must present valid card first)	1: Enable	128	7	Networking/Stand-Alone				

◎Add value 032 means to activate, deduct value of 032 means to disactivate the function of swipe any tags to release door open

28 * ??? #								
Function	C	Option	Value	Bit	Application			
Expiry User Access Trigger Alarm	%0: Disable	1: Enable	001	0	Networking/Stand-Alone			
Reset Anti-Passback on Timezone 61	%0: Disable	1: Enable	002	1	Networking/Stand-Alone			
			004	2				
Duress and Arming Output function	0: Wiegand Output	0: Wiegand Output 1: Arming and Duress Output			Networking/S <mark>tand-Alo</mark> ne			
	Lift Control: 0							
	Host: 1							
RS-485	LED Board: 1			4-5	Networking/Stand-Alone			
	Printer: 1		048					
			032	6				
			064	7				

34 * ??? #					*Default Value
Function		Option	Value	Bit	Application
Turn off buzzer function	%0∶Disable	1 : Enable	001	0	Networking/Stand-Alone
Any error trigger alarm (ex: swipe invalid card)	%0∶Disable	1 : Enable	002	1	Networking/Stand-Alone
Reserved	%0∶Disable	1 : Enable	004	2	Networking/Stand-Alone
Turn off 13.56MHz reading function	%0∶Disable	1 : Enable	008	3	Networking/Stand-Alone
Turn off 125kHz reading function	%0∶Disable	1 : Enable	016	4	Networking/Stand-Alone
	-		-	-	

44 *) ??? #)									
Function		Option	Value	Bit	Application				
Access valid door relay remain locked	isable ≫0∶Disable	1 : Enable	001	0	Networking/Stand-Alone				
Master/Slave interlocking (Master open, Slave could not open door)	%0∶Disable	1: Enable	002	1	Networking/Stand-Alone				
Reserved	%0∶Disable	1 : Enable	004	2	Networking/Stand-Alone				
Stop card access (access only by PIN or PC remote open door)	%0:Disable	1 : Enable	008	3	Networking/Stand-Alone				
Reserved	%0∶Disable	1 : Enable	016	4	Networking/Stand-Alone				

**More Details :** <u>Introduction of New Function Commands for Enterprise E Controller and Home H Controller</u>



### 03. Adding and Deleting Tag

#### Add New Tags

#### Add by Presenting Tags (apply to Single Tag or a Batch of Tags)

**\*Important Notice:** Please remember the last user address being added to make sure the old user data is not being over written with the new card in the future.

#### Add Non-consecutive Tags:

[Add single tag] Add a new tag for selected user address 100:

Enter program mode  $\rightarrow$  19 \* 00100 \* 00001 #  $\rightarrow$  Present the tag  $\rightarrow$  Successfully added tag of user 100

[Add 2 additional tags] Add new tags to the following user address 101-102:

Enter program mode  $\rightarrow$  19 \* 00101 \* 00001 #  $\rightarrow$  Present (User 101) card  $\rightarrow$  Present (User 102) card

 $\rightarrow$  Successfully added tags of user 101-102

[Add 10 additional tags] Add new tags to the following user address 103-112

Enter program mode  $\rightarrow$  19 \* 00103 \* 00001 #  $\rightarrow$  Present (User 103) card  $\rightarrow$  Present (User 104) card  $\rightarrow$  Present (...) card  $\rightarrow$  Present (User 111) card  $\rightarrow$  Present (User 112) card  $\rightarrow$  Successfully added tags of user 103-112

Add Consecutive Tags:

[Add 50 consecutive tags] Add 50 new tags with consecutive card number following user address 00050-00150:

Enter program mode  $\rightarrow$  19 \* 00050 \* 001001 #  $\rightarrow$  Successfully added tags of user 50-150

#### **Delete Tags**

#### Delete Single Tag or a Batch of Tags (by User Address)

- Input \*123456 # (or Master Code)  $\rightarrow 10 *$  SSSSS 9 EEEEE #
- [e.g.] Delete User Address: 00058 Enter program mode → 10 ★ 00058 9 00058 #
- [e.g.] Delete User Address: 00058~00063 Enter program mode → 10 ★ 00058 9 00063 #

#### Delete All Tags

Input \*123456 # (or Master Code)  $\rightarrow$  29 \*29 \* #



# O4. Programming A. Entering and Exiting Programming Mode Entering Input ★123456 #) or ★PPPPPP # [e.g.] The Default Value= 123456, if already changed the Master Code= 876112, input ★876112 #) → Access programming mode Exiting Input ★ # Changing the Master Code Access programming mode → 09 ★PPPPPRRRRR #) [Input the 6-digit new master code twice.] [e.g.] If want to changing the Master Code= 876112, input ★123456 #) → 09 ★876112876112 #) B. Changing the Node ID of Reader

Access programming mode → 00 **\***NNN **\***MMM **\***AAA **#** [NNN= Node ID: 000~254; MMM=AR-725-E Door NO.:1~255; AAA=WG Reader Door NO.:1~255



#### C.Setting up the control mode (M4/M8)

Access programming mode  $\rightarrow 04 \text{ * } N \text{ # } [N=4/8]$ 

(Note : The modification of controller mode between M4/M8(networking) and M6(standalone) will reset the data, user data will be required to rebuild.)

Mode	Support	User Capacity	Access Mode	Event Capacity	120 Holidays	Duress	Time Zone	Lift Control	Anti-pass- back
M4	Networking/ Stand-Alone	16,000 (0~15,999)	1.Card only 2.Card and PIN (4-8 digit PIN Can be set) 3.Card or User address (5-digit) + Individual PIN (4-8 digit individual PIN Can be set )	32,000	v	V	unlimited	64	V
M8	Networking/ Stand-Alone	16,000 (0~15,999)	1.Card only 2.Card and PIN (4-8 digit individual PIN Can be set) 3.Card or PIN (4-8 digit individual PIN Can be set)	32,000	V	V	unlimited	64	V

#### D. Setting up the password

#### Individual PWD (M4/M8)

**Card or PIN:** Access programming mode  $\rightarrow$  12 \*UUUUU \*PPPP # [e.g. User address: 00001 and PWD: 1234. Input 12 \* 00001 \* 1234 # ] **Card and PIN:** Access programming mode  $\rightarrow$  13 \* UUUUU \* PPPP # [e.g. User address: 00001 and PWD: 1234. Input 13 \* 00001 \* 1234 # ]

#### E. PIN & UID Length setting

Access programming mode → 42 \* m \* n # [m=PIN code Length 4~8 Digit ; n = UID Length 2~8 Digit ] (4 is default value)
 Example:42 \* 8 \* 4 # [PIN code Length 8 Digit ; UID Length 4 Digit ]

#### E. Anti-pass-back

Usually, anti-pass-back is commonly applied to parking areas in order to prevent from multi-entry with one card at a time, or somewhere wants to monitor not only the access but also exit condition.

#### Enable device

Access programming mode  $\rightarrow$  20  $\pm$  0 or 1  $\pm$  ??? # 0 or 1= Enable target unit (0=Main Controller Parameter Setting,1=WG Input Port Parameter Setting) [e.g.] If the **AR-363-E** set to **exit reader**, **WG Reader** set to **access reader**.

Access programming mode  $\rightarrow$  20 \* 0 \* 128 #  $\rightarrow$  20 \* 1 \* 192 # [Please refer to <u>Compound Command Function List</u> for details.]

#### Enable card user

Access programming mode  $\rightarrow 26 \text{ }\text{SSSSS} \text{ }\text{EEEEE} \text{ }P \text{ }\text{}$  SSSSS= starting user address; EEEE= ending user address [P=0 Enable/ P=1 Disable/ P=2 Reset] [e.g.] User address from 00152 to 00684 enable the anti-pass-back function: 26 00152 00684 0

#### F. Auto Open Access (uncontrolled) Time Zone – Automatically Release Door Lock

Door will remain open after flashing one valid card. When the reader is stand-alone, supporting only 16 sets of auto-open zone by device setting. Auto-open zone can extend up to unlimited sets by Networking. Please refer to paragraph <u>Compound Command Function List</u> below to ensure command

20 \* 0 or 1 \*??? # / 24 \* 0 or 1 \*??? # will not reset the functions that already had been changed.

Enable/Disable auto open zone

Access programming mode  $\rightarrow$  20  $\pm$  0 or 1  $\pm$  ??? # 0 or 1= Enable target unit(0=Main Controller Parameter Setting,1=WG Input Port Parameter Setting) [e.g.] If the **AR-363-E** set to **Enable aut open zone**.

Access programming mode → 20 \* 0 \* 004 # [Please refer to <u>Compound Command Function List</u> for details.]

#### • Enable/Disable auto open door without presenting one valid card and Automatically release door lock when auto open time is up Access programming mode → 24 \* 0 or 1 \*??? # 0 or 1= Enable target unit(0=Main Controller Parameter Setting,1=WG Input Port Parameter Setting) [Please refer to <u>Compound Command Function List</u> for details.]

[e.g.] If the WG Reader set to Enable aut open door without presenting card.

Access programming mode → 24 \*1 \*128 # [Please refer to Compound Command Function List for details.]

**Illuminated Touch-panel** 

## 

V250108

#### Set up auto-open time zone

Access programming mode  $\rightarrow$  08 \* MW \* NN \* HHMMhhmm \* 7123456H # [M=AR-725-E; W=Reader(0=disable,1=enable); NN: 16 sets of auto-open zone (NN=00~15); HHMMhhmm=Starting time to ending time; 7123456H= 7 days of week + Holiday (F= 0: disable; 1: enable)] [e.g.]AR-725-E (without WG reader), to set second time zone which could be passed only at 9:30am to 4:20pm on Mon, Wed and Fri. Access programming mode  $\rightarrow$  08 \* 10 \* 01 \* 09301620 \* 01010100 #  $\rightarrow$  setting is completed

#### G. Lift control

Connect with AR-401-IO-0016R to control floors which the user will be able to access. [BAUD9600]

#### Single floor

Access programming mode  $\rightarrow 27 \text{ *} \text{UUUUU *} \text{LL } \text{#}$ UUUU=User Address LL=Floor number (01~64 floor) [e.g.] User address NO. 45 only can reach the elevator to the 24th floor: 27 \* 00045 \* 24 #]

#### Multi floors

Access programming mode → 21 ★UUUUU ★G ★LLLLLLL # [UUUUU=User address G: 8 sets of lift control (Input: 0~7) LLLLLLLL: 8 floors setting (L=0=Disable, L=1=Enable)

[e.g.] User address NO. 168 can reach only the 6th and 20th floor: Access programming mode  $\rightarrow 21 \pm 00168 \pm 0 \pm 00100000 \#$  $\rightarrow 21 \pm 00168 \pm 2 \pm 00001000 \#$ 

Set	Floor								
(G)	L	L	L	L	L	L	L	L	
0	8	7	6	5	4	3	2	1	
1	16	15	14	13	12	11	10	9	
2	24	23	22	21	20	19	18	17	
3	32	31	30	29	28	27	26	25	
4	40	39	38	37	36	35	34	33	
5	48	47	46	45	44	43	42	41	
6	56	55	54	53	52	51	<b>5</b> 0	49	
7	64	63	62	61	60	59	<mark>5</mark> 8	57	

#### H. Setting Up the Arming

In the security management of access control system, the controller or reader status is divided into Standby Mode or Disarming Mode and Arming Mode. The conditions for triggering the alarm in these two modes is different, as shown in the following comparison:

#### Alarm conditions:

• Application:

1. Door is forced open

- Application:
- **1. Door open too long**: Door is open longer than door relay time plus door close time.
- 2. Force open (Opened without a valid user card): Access by force or illegal procedure.
- 3. Door position abnormal: Arming is enabled and the power is suddenly off then on.





2.Abnormal Opening								
	Green Led Flash	Green Led Flash Quickly Red L	_ed Flash Quickly					
	Enable Arming Arming Dela	ay TM 🗿 🕑 Alarm Delay TM 🧖	Alarm Relay TM					
	Standby Mode		Narm trigger					
	(Arming is not enable)	Enable Alarm Trigge	r					
		Arming Status						
•	Enable Arming status:							
	Standby Mode							
	Card only		Card or Passcode	Card and Passcode				
		Enable particular device	Input 5 digit user address $\rightarrow$ Input 4	Induct valid card $\rightarrow$ input 4 digit pass				
	induct valid card $\rightarrow$ input 4 digit	arming code $\rightarrow$ *0 or 1 # or #	digit pass code $\rightarrow \# \rightarrow$ input 4 digits	$code \rightarrow \# \rightarrow mput 4 digits anning$				
	Enter Program Mode							
	Enable all devices: Access program	ming mode $\rightarrow * * #$	Enable particular device: Access	programming mode $\rightarrow * * 0$ or 1 #				
•	Standby Mode							
	Stanuby Wode		Card or Passoode	Card and Passoode				
	Disable all devices	Disable particular device	$\begin{array}{c} \text{Card of Fasscode} \\ \text{Input 5 digit user address} \rightarrow \text{Input 4} \end{array}$	Induct valid card → Input 4 digit pase				
	Induct valid card $\rightarrow$ Input 4 digit	Induct valid card $\rightarrow$ Input 4 digit	digit pass code $\rightarrow \# \rightarrow \text{Input 4}$ digits	$code \rightarrow \# \rightarrow lnput 4 digits arming$				
	arming code $\rightarrow$ * 9 #	arming code $\rightarrow *0$ or 1 # or #	arming code $\rightarrow * 9 \# \text{ or } * 0 \text{ or } 1 \#$	$code \rightarrow * 9 \# or * 0 or 1 \#$				
	* Factory default anningcode is:	1234. 0 or 1=Reader unit (0=Main	Controller Parameter Setting,1=wG	input Port Parameter Setting ).				
<ul> <li>05. Restoring Factory Settings</li> <li>Reset all device parameters and user card data</li> <li>Reset User Data : <ul> <li>Access programming mode → 29 * 29 * #</li> </ul> </li> <li>Reset User Data &amp;Controller Parameter : <ul> <li>Access programming mode → 29 * 20 * #</li> </ul> </li> <li>Reset User Data &amp;Controller Parameter (incl. Master Code) <ul> <li>&amp; Reset Vser Data &amp;Controller Parameter (incl. Master Code)</li> <li>&amp; Reset Parameter Setting- SOR : <ul> <li>Access programming mode → 29 * 21 * #</li> </ul> </li> <li>Reset IP Setting: <ul> <li>Access programming mode → Press "IP Resent Button" of main board for few seconds. (Reference to picture)</li> </ul> </li> <li>* After operation as above, you will hear the long reminder sound, and wait until the sound disappear then reset the power of the controller, the device will restore factory setting.</li> </ul></li></ul>								
Get the upgrade software from SOYAL or our distributor and run "UdpUpdater" software								
	Execute the software 📱 IIda Under	er eve	at, Controller update tool (Ver 3.00) NET Adapter [192:168.1.21; 90-79-59-62-4e-23; (Realtek PCIe GBE Family Controller #3)	2 4				
	The software is Login the SOVAL web	a to downloads	Firmware 0x0000	Load FW Update F/W Load Fort Update Fort				
	The soltware is Login the SOTAL Wel		Ide Image 72705MRO Test 00 13 57 01 02 03 plantery evalue or	Load Image Update Image				
	Update the firmware		Update Path 9 Ethemet IP 192:168.1.127 Port 1604 Node 1 @ @ ##	×				
2	[Please login the SOYAL web to do	wnload the new ISP Firmware.1	● Serial Node (COM) 1 区DM1 Serial Pont (COM) 8AUD 彩密度称声	E.725tv2 >				
	1. Input the Target Address and Port		Uniter Put (County and O           0115200 ⊕ 57600 038400 019200 09600 04800           Select Dwice	会編 ▲解5725542_V0404_220914.5TM 2022,9/14 下午 0 STM 推開				
	2. [Load F/W] open the documents th	at have the new ISP Firmware	CPTV2     CPTV2					
	3. Click the new ISP Firmware and IO	pen] it	(3)31E/327E/721Ev2/722Ev3/881E/821Ev5/837E/EF     New Data (R)     101/321/401/721723725/888 H-K-Uarm     Temp (T)					
	4. Click [Update Device] to start the fi	rmware update	● #88 ○	沒對強難司用				
	5. Till the screen shown [Firmware Up	odate is Complete]	SOVALZBERDY					
		-	CONTROLLER(192.168.001.172) Firmware Update is Completed !					

\* More Details : Software Manual - UDP UPDATER

der address is 192.168.1.128 (1604)

SOYAL379ADA SOYAL394CIND
 SOYAL432AND'
 SOYAL510RICKI
 SOYAL510RICKI

檔案名稱(N): APS725Ev2\_V0404\_22091

Firmware Files(\*stm;\*at3;\*.ui ~
 開放(O) 股湯

Illuminated Touch-panel

## 

V250108

n octang					
open your Web Brow	ser and input factory default IP	S2E - Windows Internet Expl	lorer		
ddress: http://192.16	8.1.127	▲ 新聞 (1) 2.163.1.	1277 約局者(A) 工具(D) 説明(B)		
		🖈 🏘 <b>S</b> 52E			🟠 • 🔂 - 🖶 • 🕃 MAQ • 🎯 IAQ
If the	IP address of AR-363-E has		AR-363-E Access Control		SOYAL
chan	ged We must enter the new				ACCESS CONTROLLER
IP ac	Idress.	Current State	Current IP Addresses Remote IP(Port) State 192 168 001 052 (0080) CONNECTED		
		Network Setting	192.168.001.052:(0080) CONNECTED Name Type IP address	Subnet mask	Gateway DHCP
		User Password	et1 Ethernet 192.168.1.127	255.255.255.0	192.168.1.254
age menu					
urrent State	Monitor the on line computer				
etwork Setting <	IP Setting				
ser Password	Change the Log-In Information				
urrent State			Current IP Addresses Current State Remote IP (Port) State		
nline Status is able to	monitor and show which computer	is linking on	192.168.001.052.(0080) CONNECTED           192.168.001.052.(0080) CONNECTED           Name         Type           Name         Type	Subnet mask	Gateway DHCP
thernet Module	Show which computer is linking _	-	User Password et1 Ethernet 192.168.1.127	255.255.255.0	192.168.1.254
	on Ethernet Module.		Î.		
	Current IP address of the AR-363-E				
an in Haar Daarwar					
/bon you obcooo the '	u "Notworking Sotting" or "I loor Dooo	word" at first			
	networking Setting of User Pass	woru at mst.			
bg-in window will pop	out and please input				
At the Factory Detail	ult				
ser name: SuperAdm				Authentication	Required
assword: 721568					and a contract of a contract of the second
				http://192.168.1.12	27 requires a username and password.
NOTE :				Your connection to	27 requires a username and password. o this site is not private.
NOTE :				http://192.168.1.12 Your connection to	27 requires a username and password. o this site is not private.
• User Name is different	ent from old and new version, passwo	ord can be mod	dify via [User Password]	http://192.168.1.12 Your connection to User Name:	27 requires a username and password. this site is not private. SuperAdm
NOTE : User Name is differently user the solution is press	ent from old and new version, passwo it will not be change from updating ne ing Reset Button to reset it as default	ord can be mod ew version. If y	dify via [User Password] ou forgot the password,	http://192.168.1.12 Your connection to User Name: Password:	27 requires a username and password. o this site is not private.           SuperAdm           721568
NOTE : User Name is different setting on the list but the solution is press	ent from old and new version, passwo it will not be change from updating ne ing Reset Button to reset it as default	ord can be mod ew version. If y t value.	dify via [User Password] ou forgot the password,	http://192.168.1.12 Your connection to User Name: Password:	27 requires a username and password. o this site is not private. SuperAdm 721568
NOTE : User Name is different setting on the list but the solution is press Firmware Version	ent from old and new version, passwo it will not be change from updating ne ing Reset Button to reset it as default User name Password (changeab	ord can be moo ew version. If y : value. ble)	dify via [User Password] ou forgot the password,	http://192.168.1.12 Your connection to User Name: Password:	27 requires a username and password. this site is not private. SuperAdm 721568 Log In Cancel
NOTE : User Name is differ setting on the list but the solution is press Firmware Version After 2020/01/21	ent from old and new version, passwo it will not be change from updating ne ing Reset Button to reset it as default User name Password (changeat SuperAdm Default Password : 721	ord can be moo ew version. If y t value. ole) 568 or self-defini	dify via [User Password] ou forgot the password, ition	http://192.168.1.12 Your connection to User Name: Password:	27 requires a username and password. this site is not private. SuperAdm 721568 Log In Cancel
NOTE : User Name is different setting on the list but the solution is press Firmware Version After 2020/01/21 Before 2020/01/21	ent from old and new version, passwo It will not be change from updating ne ing Reset Button to reset it as default User name Password (changeab SuperAdm Default Password : 721 admin Default Password : adm	ord can be mod ew version. If y t value. ble) 568 or self-defini	dify via [User Password] ou forgot the password, tion	http://192.168.1.12 Your connection to User Name: Password:	27 requires a username and password. this site is not private. SuperAdm 721568 Log In Cancel
NOTE : User Name is differ setting on the list but the solution is press Firmware Version After 2020/01/21 Before 2020/01/21	ent from old and new version, passwo it will not be change from updating ne ing Reset Button to reset it as default User name Password (changeab SuperAdm Default Password : 721 admin Default Password : adm	ord can be moo ew version. If y t value. ble) 568 or self-defini in/ password no	dify via [User Password] ou forgot the password, ition t required or self-definition	http://192.168.1.12 Your connection to User Name: Password:	27 requires a username and password. o this site is not private. SuperAdm 721568 Log In Cancel
NOTE : User Name is different setting on the list but the solution is press Firmware Version After 2020/01/21 Before 2020/01/21	ent from old and new version, passwo it will not be change from updating ne ing Reset Button to reset it as default User name Password (changeat SuperAdm Default Password : 721 admin Default Password : adm	ord can be mod ew version. If y t value. ble) 568 or self-defini in/ password no	dify via [User Password] ou forgot the password, tion t required or self-definition	http://192.168.1.12 Your connection to User Name: Password:	27 requires a username and password. o this site is not private. SuperAdm 721568 Log In Cancel
NOTE : User Name is differ setting on the list but the solution is press Firmware Version After 2020/01/21 Before 2020/01/21	ent from old and new version, passwo it will not be change from updating ne ing Reset Button to reset it as default User name Password (changeat SuperAdm Default Password : 721 admin Default Password : adm	ord can be mod ew version. If y t value. ble) 568 or self-defini in/ password no	tify via [User Password] ou forgot the password, ition t required or self-definition	Nttp://192.168.1.12 Your connection to User Name: Password:	27 requires a username and password. o this site is not private. SuperAdm 721568 Log In Cancel
NOTE : User Name is differ setting on the list bu the solution is press Firmware Version After 2020/01/21 Before 2020/01/21	ent from old and new version, passwo at will not be change from updating ne ing Reset Button to reset it as default User name Password (changeat SuperAdm Default Password : 721 admin Default Password : adm	ord can be mod ew version. If y : value. 568 or self-defini in/ password not	dify via [User Password] ou forgot the password, ition t required or self-definition	http://192.168.1.12 Your connection to User Name: Password:	27 requires a username and password. to this site is not private. SuperAdm 721568 Log In Cancel
IOTE : User Name is differ setting on the list but the solution is press Firmware Version After 2020/01/21 Before 2020/01/21	ent from old and new version, passwo at will not be change from updating ne ing Reset Button to reset it as default User name Password (changeat SuperAdm Default Password : 721 admin Default Password : adm	ord can be mod ew version. If y a value. ble) 568 or self-defini in/ password nor	dify via [User Password] ou forgot the password, ition t required or self-definition	http://192.168.1.12 Your connection to User Name: Password:	27 requires a username and password. this site is not private. SuperAdm 721568 Log In Cancel
IOTE : User Name is differ setting on the list but the solution is press Firmware Version After 2020/01/21 Before 2020/01/21	ent from old and new version, passwo tt will not be change from updating ne ing Reset Button to reset it as default User name Password (changeab SuperAdm Default Password : 721 admin Default Password : adm	brd can be mod ew version. If y a value. ble) 568 or self-defini in/ password not	dify via [User Password] ou forgot the password, tition t required or self-definition	http://192.168.1.12 Your connection to User Name: Password:	Z7 requires a username and password. to this site is not private.  SuperAdm 721568  Log In Cancel  Cancel  Cancel  Cancel  Cancel
NOTE : User Name is different setting on the list but the solution is press Firmware Version After 2020/01/21 Before 2020/01/21	ent from old and new version, passwo at will not be change from updating ne ing Reset Button to reset it as default User name Password (changeab SuperAdm Default Password : 721 admin Default Password : adm	brd can be mod ew version. If y a value. ble) 568 or self-defini in/ password no 668 or self-defini in/ password no	dify via [User Password] ou forgot the password, tition t required or self-definition	http://192.168.1.12 Your connection to User Name: Password:	27 requires a username and password. this site is not private. SuperAdm 721568 Log In Cancel © M ←  ×  Couple © M ←  ×  Couple © M ←  ×  Couple
NOTE : User Name is different setting on the list but the solution is pressed Firmware Version After 2020/01/21 Before 2020/01/21 Before 2020/01/21 Betworking Setting but will find initial IP Ar AC Address is the same	ent from old and new version, passwo at will not be change from updating ne ing Reset Button to reset it as default User name Password (changeab SuperAdm Default Password : 721 admin Default Password : adm ddress 192.168.1.127 and check me as sticker on Ethernet Module	brd can be modew version. If y a value. ble) 568 or self-defini in/ password not	tion t required or self-definition  Real Engine AR-363-E Access Com	http://192.168.1.12 Your connection to User Name: Password:	27 requires a username and password. this site is not private. SuperAdm 721568 Log In Cancel © ♥ ♥   ♥ Conde © ♥ ♥   ♥ Conde © ♥ ♥   ♥ Conde
NOTE : User Name is differ setting on the list but the solution is press Firmware Version After 2020/01/21 Before 2020/01/21 Before 2020/01/21	ent from old and new version, passwo at will not be change from updating ne ing Reset Button to reset it as default User name Password (changeat SuperAdm Default Password : 721 admin Default Password : adm ddress 192.168.1.127 and check me as sticker on Ethernet Module IP address you want, and then click	ord can be modew version. If y         aw version. If y         t value.         568 or self-definition         in/ password no         Image: Self transformer law         Image: Self t	tion t required or self-definition t required or self-definition AR-363-E Access Com	http://192.168.1.12 Your connection to User Name: Password: trol	27 requires a username and password. this site is not private.  SuperAdm 721568  Log In Cancel
NOTE : User Name is differ setting on the list but the solution is press Firmware Version After 2020/01/21 Before 2020/01/21 Before 2020/01/21 etworking Setting but will find initial IP A AC Address is the satisfies of the satisfiest vice. Please revise pdate" button. After	ent from old and new version, passwo it will not be change from updating ne ing Reset Button to reset it as default User name Password (changeat SuperAdm Default Password : 721 admin Default Password : adm ddress 192.168.1.127 and check me as sticker on Ethernet Module IP address you want, and then click updating the IP, please re-connect	ord can be mod ew version. If y i value. 568 or self-defini in/ password noi in/ password noi	dify via [User Password] ou forgot the password, ition t required or self-definition	trol	27 requires a username and password. to this site is not private.  SuperAdm 721568  Log In Cancel  Cancel Cancel Cancel Cancel Cancel Cancel Cancel Cancel Cancel Cancel Cancel Cancel Cancel Cancel Cancel
IOTE : User Name is differ setting on the list but the solution is press Firmware Version After 2020/01/21 Before 2020/01/21 Before 2020/01/21 u will find initial IP A AC Address is the sa vice. Please revise pdate" button. After	ent from old and new version, passwo it will not be change from updating ne ing Reset Button to reset it as default User name Password (changeat SuperAdm Default Password : 721 admin Default Password : adm ddress 192.168.1.127 and check me as sticker on Ethernet Module IP address you want, and then click updating the IP, please re-connect aw IP address.	ord can be mod ew version. If y i value. 568 or self-defini in/ password nor in/ password n	dify via [User Password] ou forgot the password, tition t required or self-definition  set Explore Area Solar E Access Conta Network Setting After you have changed the IP address, the You need to change the host IP with new if	http://192.168.1.12 Your connection to User Name: Password: Password: trol	27 requires a username and password. to this site is not private. SuperAdm 721568 Log In Cancel Cancel Cancel Cancel Cancel Content Cancel Cancel Cancel Cancel Cancel Cancel Cancel Cancel Cancel Cancel Cancel Cancel Cancel Content Cancel Content Cancel Content Cancel Cancel Cancel Content Cancel Content Cancel Content Cancel Content Cancel Content Cancel Content Cancel Content Cancel Content Cancel Content Cancel Content Cancel Content Cancel Content Cancel Content Cancel Content Cancel Content Cancel Content Cancel Content Cancel Content Cancel Content Content Cancel Content Conte
NOTE : User Name is differ setting on the list but the solution is press Firmware Version After 2020/01/21 Before 2020/01/21 Before 2020/01/21 etworking Setting u will find initial IP A AC Address is the sa vice. Please revise pdate" button. After the Web Browser by ne	ent from old and new version, passwo it will not be change from updating ne ing Reset Button to reset it as default User name Password (changeat SuperAdm Default Password : 721 admin Default Password : adm ddress 192.168.1.127 and check me as sticker on Ethernet Module IP address you want, and then click updating the IP, please re-connect aw IP address.	ord can be mod ew version. If y i value. 568 or self-defini in/ password nor in/ password nor in/ password nor in/ password nor in/ password nor in/ in/ in/ in/ in/ in/ in/ in/ in/ in/	dify via [User Password] ou forgot the password, ition t required or self-definition	http://192.168.1.12 Your connection to User Name: Password: Password: trol	27 requires a username and password. to this site is not private. SuperAdm 721568 Log In Cancel
IOTE : User Name is differ setting on the list but the solution is press Firmware Version After 2020/01/21 Before 2020/01/21 Before 2020/01/21 User Strong u will find initial IP Ar AC Address is the sat vice. Please revise pdate" button. After a Web Browser by ne	ent from old and new version, password it will not be change from updating ne ing Reset Button to reset it as default User name Password (changeat SuperAdm Default Password : 721 admin Default Password : adm ddress 192.168.1.127 and check me as sticker on Ethernet Module IP address you want, and then click updating the IP, please re-connect aw IP address.	ord can be mod ew version. If y i value. 568 or self-defini in/ password nor in/ password nor in/ password nor in/ password nor in/ in/ password nor in/ in/ password nor in/ in/ password nor in/ in/ in/ in/ in/ in/ in/ in/ in/ in/	tition t required or self-definition  T required or self-definition  AR-363-E Access Cont AR-363-E Access Cont After you have changed the IP address, the You need to change the heat IP with new IF Device Name LANI P Address	trol  device will restart (hardware rese Paddress in Internet Browser to re ControlLER  192181.112	27 requires a username and password. to this site is not private. SuperAdm 721568 Log In Cancel Cancel Cancel Cancel Cancel Conde Cancel C
IOTE : User Name is differ setting on the list but the solution is press Firmware Version After 2020/01/21 Before 2020/01/21 Before 2020/01/21 etworking Setting u will find initial IP A AC Address is the sat vice. Please revise pdate" button. After the Web Browser by ne	ent from old and new version, passwo it will not be change from updating ne ing Reset Button to reset it as default User name Password (changeat SuperAdm Default Password : 721 admin Default Password : adm ddress 192.168.1.127 and check me as sticker on Ethernet Module IP address you want, and then click updating the IP, please re-connect aw IP address.	Drd can be mod ew version. If y is value. 568 or self-defini in/ password not in/ password not in/ password not in/ password not in/ password not in/ in/ in/ in/ in/ in/ in/ in/ in/ in/	tition t required or self-definition t required or self-definition t AR-363-E Access Cont After you have changed the IP address, the You need to change the heat IP with new IF Device Name LANI P Address LAN Net Mark	http://192.168.1.12 Your connection to User Name: Password: Password: trol	27 requires a username and password. to this site is not private. SuperAdm 721568 Log In Cancel
IOTE : User Name is differ setting on the list but the solution is press Firmware Version After 2020/01/21 Before 2020/01/21 Before 2020/01/21 etworking Setting u will find initial IP A AC Address is the sa vice. Please revise pdate" button. After a Web Browser by ne	ent from old and new version, passwo at will not be change from updating ne ing Reset Button to reset it as default User name Password (changeat SuperAdm Default Password : 721 admin Default Password : adm ddress 192.168.1.127 and check me as sticker on Ethernet Module IP address you want, and then click updating the IP, please re-connect aw IP address.	brd can be mod ew version. If y e value. 568 or self-defini in/ password not in/ password n	tion trequired or self-definition  trequired or self-definition  AR-363-E Access Cont Alter you have changed the IP address, the You need to change the host IP with new IP  Device Name LAN IP Address LAN Net Mask Defaul Gateway Primary DNS Server	http://192.168.1.12 Your connection to User Name: Password: trol a device will restart (hardware ress P Address in Internet Browser to re CONTROLLER [192.161.127 [255.6235.0] [192.161.127 [255.6235.0] [192.161.127 [255.6235.0] [192.161.127 [255.6235.0] [192.161.127 [255.6235.0] [192.161.127	e). etting
IOTE : User Name is differ setting on the list but the solution is press Firmware Version After 2020/01/21 Before 2020/01/21 Before 2020/01/21 User Working Setting u will find initial IP A AC Address is the sa vice. Please revise pdate" button. After web Browser by ne	ent from old and new version, passwo at will not be change from updating ne ing Reset Button to reset it as default User name Password (changeat SuperAdm Default Password : 721 admin Default Password : adm ddress 192.168.1.127 and check me as sticker on Ethernet Module IP address you want, and then click updating the IP, please re-connect ew IP address.	ord can be mod ew version. If y e value. 568 or self-defini in/ password nor in/ password n		ttp://192.168.1.12 Your connection to User Name: Password: trol device will restart (hardware rese P Address in Internet Browser to re P Address in Internet Browser to re	27 requires a username and password. to this site is not private. SuperAdm 721568 Log In Cancel
IOTE : User Name is differ setting on the list but the solution is press Firmware Version After 2020/01/21 Before 2020/01/21 User 2020/01/21 User 2020/01/21 Before 2020/01/21 User 2020/01/21 Before 2020/01/21 Before 2020/01/21 Before 2020/01/21 Before 2020/01/21 Before 2020/01/21	ent from old and new version, passwo at will not be change from updating ne ing Reset Button to reset it as default User name Password (changeat SuperAdm Default Password : 721 admin Default Password : adm ddress 192.168.1.127 and check me as sticker on Ethernet Module IP address you want, and then click updating the IP, please re-connect aw IP address.	ord can be modew version. If y i value. 568 or self-defini in/ password nor in/ password nor in/ in/ in/ in/ in/ in/ in/ in/ in/ in/		trol  controlLER  statistic  statistic  controlLER  statistic  statistic  controlLER  stati	27 requires a username and password. to this site is not private. SuperAdm 721568 Log In Cancel
IOTE : User Name is differ setting on the list but the solution is press Firmware Version After 2020/01/21 Before 2020/01/21 Before 2020/01/21 u will find initial IP A AC Address is the sa vice. Please revise pdate" button. After the Web Browser by ne	ent from old and new version, password it will not be change from updating ne ing Reset Button to reset it as default User name Password (changeat SuperAdm Default Password : 721 admin Default Password : adm ddress 192.168.1.127 and check me as sticker on Ethernet Module IP address you want, and then click updating the IP, please re-connect aw IP address.	ord can be mod ew version. If y i value. 568 or self-defini in/ password noi in/ password noi in/ in/ in/ in/ in/ in/ in/ in/ in/ in/		trtp://192.168.1.12 Your connection to User Name: Password: trol edevice will restart (hardware rese P Address in Internet Browser to re P Address in Internet Browser to re	27 requires a username and password. to this site is not private. SuperAdm 721568 Log In Cancel Cancel Cancel Cancel Cancel Content Cancel Content Cancel Content Cancel Content Cancel Content Cancel Content Cancel Content Cancel Content Cancel Content Cancel Content Cancel Content Content Cancel Content Cancel Content
NOTE : User Name is different setting on the list but the solution is press Firmware Version After 2020/01/21 Before 2020/01/21 Before 2020/01/21 Betworking Setting but will find initial IP Ar AC Address is the sate vice. Please revise Ipdate" button. After the Web Browser by not	ent from old and new version, passwo it will not be change from updating ne ing Reset Button to reset it as default User name Password (changeat SuperAdm Default Password : 721 admin Default Password : adm ddress 192.168.1.127 and check me as sticker on Ethernet Module IP address you want, and then click updating the IP, please re-connect aw IP address.	ord can be modew version. If y a value. 568 or self-definition in/ password not set of the self-definition in/ password set of the set of the self-definition in/ password set of the set o		ttp://192.168.1.12 Your connection to User Name: Password: trol trol device will restart (hardware rese Paddress in Internet Browser to re Paddress in Internet Browser to re	27 requires a username and password. to this site is not private. SuperAdm 721568 Log In Cancel Cancel Cancel Cancel Cancel Consection Cancel Consection Cancel Consection Cancel Cancel Cancel Consection Cancel Cancel Cancel Consection Cancel Consection Cons
NOTE : User Name is different setting on the list but the solution is press Firmware Version After 2020/01/21 Before 2020/01/21 Before 2020/01/21 Betworking Setting but will find initial IP Ar AC Address is the sate service. Please revise Update" button. After the Web Browser by new Setting Setting Setting Setting Setting Setting Setting Setting Setting Setting Setting Setting Setting Setting Setting S	ent from old and new version, passwo it will not be change from updating ne ing Reset Button to reset it as default User name Password (changeat SuperAdm Default Password : 7218 admin Default Password : adm ddress 192.168.1.127 and check me as sticker on Ethernet Module IP address you want, and then click updating the IP, please re-connect aw IP address.	Drd can be modew version. If y a value. 568 or self-definition in/ password not set of set of self-definition in/ password not set of set of set of set set of set of set of set of set	tion trequired or self-definition  trequired or self-definition  AR-363-E Access Cont After you have changed the IP address, the You need to change the host IP with new EAN IP Address LAN Net Mask Default Gateway Primary DNS Server MaC Address LAN Net Mask Default Gateway Primary DNS Server MaC Address LAN Net Mask Default Gateway Primary DNS Server MaC Address LAN Net Mask Default Gateway Primary DNS Server MaC Address LAN Net Mask Default Gateway Primary DNS Server MaC Address LAN Net Mask Default Gateway Primary DNS Server MaC Address LAN Net Mask Default Gateway Primary DNS Server MaC Address LAN Net Mask Default Gateway Primary DNS Server MaC Address LAN Net Mask Default Gateway Primary DNS Server MaC Address LAN Net Mask Default Gateway Primary DNS Server MaC Address LAN Net Mask Default Gateway Primary DNS Server MaC Address LAN Net Mask Default Gateway Primary DNS Server MaC Address LAN Net Mask Default Gateway Primary DNS Server MaC Address LAN Net Mask Default Gateway Primary DNS Server MaC Address LAN Net Mask Default Gateway Primary DNS Server MaC Address DHCP Client TCP Listen Port	trp://192.168.1.12 Your connection to User Name: Password: trol device will restart (hardware rese Paddress in Internet Browser to re Paddress in Internet Browser to re	27 requires a username and password. to this site is not private. SuperAdm 721568 Log In Cancel Cancel Cancel Cancel Conset
NOTE : User Name is different setting on the list but the solution is press Firmware Version After 2020/01/21 Before 2020/01/21 Before 2020/01/21 Betworking Setting but will find initial IP At AC Address is the sate vice. Please revise Update" button. After the Web Browser by new Ser Password	ent from old and new version, passwo at will not be change from updating ne ing Reset Button to reset it as default User name Password (changeat SuperAdm Default Password : 7218 admin Default Password : adm ddress 192.168.1.127 and check me as sticker on Ethernet Module IP address you want, and then click updating the IP, please re-connect aw IP address.	pord can be modew version. If y         aw version. If y         svalue.         568 or self-definition         in/ password not         Im/ password	dify via [User Password] ou forgot the password, tion trequired or self-definition	trol  device will restart (hardware rese Padress in Internet Browser to re  composition to restart (hardware rese Padress in Internet Browser to re  composition to restart (hardware rese Padress in Internet Browser to re  composition to restart (hardware rese Padress in Internet Browser to re  composition to restart (hardware rese Padress in Internet Browser to re  composition to restart (hardware rese Padress in Internet Browser to re  composition to restart (hardware rese Padress in Internet Browser to re  composition to restart (hardware rese Padress in Internet Browser to re  composition to restart (hardware rese Padress in Internet Browser to re  composition to restart (hardware rese Padress in Internet Browser to re  composition to restart (hardware rese Padress in Internet Browser to re  composition to restart (hardware rese Padress in Internet Browser to re  composition to restart (hardware rese Padress in Internet Browser to re  composition to restart (hardware rese Padress in Internet Browser to re  composition to restart (hardware rese Padress in Internet Browser to re  composition to restart (hardware rese Padress in Internet Browser to re  composition to restart (hardware rese Padress in Internet Browser to re  composition to restart (hardware rese Padress in Internet Browser to re  composition to restart (hardware rese Padress in Internet Browser to re  composition to restart (hardware rese Padress in Internet Browser to re  composition to restart (hardware rese Padress in Internet Browser to re  composition to restart (hardware rese Padress in Internet Browser to re  composition to restart (hardware rese Padress in Internet Browser to re  composition to restart (hardware rese Padress in Internet Browser to re  composition to restart (hardware rese Padress in Internet Browser to re  composition to restart (hardware rese Padress in Internet Browser to re  composition to restart (hardware rese Padress in Internet Browser to re  composition to restart (hardware rese Padress in Internet Browser to re	Image: Product of the system         SuperAdm         721568         Log In         Cancel         Image: Conder         Image: Co
NOTE : User Name is different setting on the list but the solution is press Firmware Version After 2020/01/21 Before 2020/01/21 Before 2020/01/21 Before 2020/01/21 Act Address is the sate vice. Please revise pdate" button. After the Web Browser by new Ser Password hange the log-in pass	ent from old and new version, password it will not be change from updating ne ing Reset Button to reset it as default User name Password (changeat SuperAdm Default Password : 721 admin Default Password : adm ddress 192.168.1.127 and check me as sticker on Ethernet Module IP address you want, and then click updating the IP, please re-connect aw IP address.	ord can be modew version. If y         aw version. If y         status.         568 or self-definition         in/ password nor         Status         Network State         Network State         Network State         Status         Status         Status         Status         Status         Network State         Network State         Status         Status         Status         Status         Network State         Network State         Network State         Status	tition trequired or self-definition  trequired or self-definition  AR-363-E Access Cont AR-363-E Access Cont  AR-363-E Access Cont  Devork Setting  AR-you have changed the IP address, the You need to change the host IP with merif  Poetice Name LAN IP Address LAN Net Mask Defaul Cateway Primary DNS Server MAC Address DHCP Client TCP Listen Port  TCP Listen Port  TCP Listen Port	trol  device will restart (hardware rese Paddress in Internet Browser to re  lize Aldress in Internet Browser to re  contributize lize Alia lise Sigual lise Sigua	Image: Product set is not private.         SuperAdm         721568         Log In         Cancel         Image: Concel         Ima
NOTE : User Name is different setting on the list but the solution is press Firmware Version After 2020/01/21 Before 2020/01/21 Before 2020/01/21 detworking Setting but will find initial IP Ar AC Address is the sate vice. Please revise Update" button. After the Web Browser by new Ser Password hange the log-in pass hernet Module.	ent from old and new version, password it will not be change from updating ne ing Reset Button to reset it as default User name Password (changeat SuperAdm Default Password : 721 admin Default Password : adm ddress 192.168.1.127 and check me as sticker on Ethernet Module IP address you want, and then click updating the IP, please re-connect aw IP address.	pord can be modew version. If y         avalue.         568 or self-definition         in/ password not         Sevent State         Version State         Network Station         User Password         State         Network Station         Version State         Version State         Network Station         Version State         Version State <td>tion trequired or self-definition trequired</td> <td>http://192.168.1.12 Your connection to User Name: Password: trol adevice will restart (hardware rese P Address in Internet Browser to re 2 device will restart (hardware rese P Address in Internet Browser to re 192.041.127 193.041.127 193.041.12</td> <td>Image: Product the system         SuperAdm         721568         Image: Product the system         Image: Product the system         Setting</td>	tion trequired or self-definition trequired	http://192.168.1.12 Your connection to User Name: Password: trol adevice will restart (hardware rese P Address in Internet Browser to re 2 device will restart (hardware rese P Address in Internet Browser to re 192.041.127 193.041.127 193.041.12	Image: Product the system         SuperAdm         721568         Image: Product the system         Image: Product the system         Setting
NOTE : User Name is different setting on the list but the solution is press Firmware Version After 2020/01/21 Before 2020	ent from old and new version, password it will not be change from updating ne ing Reset Button to reset it as default User name Password (changeat SuperAdm Default Password : 721 admin Default Password : adm ddress 192.168.1.127 and check me as sticker on Ethernet Module IP address you want, and then click updating the IP, please re-connect aw IP address.	e	tion trequired or self-definition  trequired or self-definition  AR-363-E Access Cont  Alter vou have changed the IP address, the You need to change the IP address, the CALVIER Address, IP Address,	ttp://192.168.1.12 Your connection to User Name: Password: trol device will restart (hardware rese P Address in Internet Browser to re P Address in Internet Browser to re P Address in Internet Browser to re (192.141.127) (192.141.127 (192.141.127 (192.141.127) (192.141.127 (192.141.127) (192.141.127 (192.141.127) (192.141.127 (192.141.127) (193.141.127) (	eting
NOTE : • User Name is different setting on the list but the solution is press Firmware Version After 2020/01/21 Before 2020/01/21 Before 2020/01/21 etworking Setting but will find initial IP A AC Address is the sate voice. Please revise Update" button. After e Web Browser by new ser Password hange the log-in pass thernet Module. he password compose ther A~Z or 0~9.	ent from old and new version, password it will not be change from updating ne ing Reset Button to reset it as default User name Password (changeat SuperAdm Default Password : 7211 admin Default Password : adm ddress 192.168.1.127 and check me as sticker on Ethernet Module IP address you want, and then click updating the IP, please re-connect aw IP address.	e e e e e e e e e e e e e e e e e e e	tion trequired or self-definition trequired or self-definition trequired or self-definition AR-363-E Access Cont AR-363-E Access Cont Network Setting After you have changed the IP address, the You need to change the host IP with new IF Device Name LAN IP Address LAN Net Mask Defaul Gateway Primary DNS Server McA. Address DHCP Client TCP Listen Port treption AR-363-E Access Cont AR-363-E Access Cont AR-363-E Access Cont Context Setting AR-363-E Access Context Description AR-363-E Access Context AR-363-E Access AR-363-E Access AR-363-E Access AR-363-E Access AR-363-E Access AR-363-E Access AR-363-E A	http://192.168.1.12 Your connection to User Name: Password: trol device will restart (hardware rese Paddress in Internet Browser to re Paddress in Internet Browser to re (192.181.127) (192.181.127 (192.181.127) (192.18	et) etime etim



## 08. Notice

- 1. Tubing: The communication wires and power line should NOT be bound in the same conduit or tubing.
- 2. Cable selection: Use AWG 22-24 Shielded Twist Pair to avoid star wiring. Use CAT5 for TCP/IP connection.

3. Power supply: Don't equip reader and lock with the same power supply. The power for reader may be unstable when the lock is activating, that may make the reader malfunction. The standard installation: Door relay and lock use the same power supply, and reader use independent power supply.

## **09.** Connector Table



#### Cable: CN5 WG Port

Wire Application	Wire	Color		Description
Beeper	1	Pink		Beeper Output 5V/100mA, Low
	2	Yellow		Red LED Output 5V/20mA, Max
LED	3	Brown		Green LED Output 5V/20mA, Max
Door Output	4			Transistor Output Max. 12V/100mA
Door Output	4	Blue white		(Open Collector Active Low)
Mingand	5	Thin Green		Wiegand DAT: 0 Input
vviegand	6 Thin Blue Wiegand DAT: 1 Input		Wiegand DAT: 1 Input	
WG Door Sensor	7	Orange		Negative Trigger Input
WG Exit Switch	8	Purple		Negative Trigger Input

#### Cable: CN6

Wire Application	Wire	Color	Description
RS-485 for Lift	1	Thick Green	RS-485(B-)
Controller	2	Thick Blue	RS-485(A+)

#### Cable: CN7

Wire Application	Wire	Color	Description
	1		
	2		
TCP/IP Output	3	Orange White	Net - TX+
	4	Orange	Net - TX-
	5	Green White	Net - RX+
	6	Green	Net - RX-
	7		

#### Cable: CN3

Wire Application	Wire	Color	Description
A	1	Red	N.C.
Anu-Tamper	2	Orange	COM
Switch	3	Yellow	N.O.

#### Cable: CN4 Main Port

Wire Application	Wire	Color	Description
	aals Dalays		(N.O.)DC24V1Amp
LOCK Relay	2	Purple White	(N.C.)DC24V1Amp
Common-COM-Point	3	White	(COM)DC24V1Amp
Door Sensor	4	Orange	Negative Trigge <mark>r Input</mark>
Exit Switch	5	Purple	Negative Trigge <mark>r Input</mark>
	6	Crow	Transistor Output Max. 12V/100mA
Alamin Relay	0	Giay	(Open Collector Active Low)
Dowor	7	Thick Red	DC 12V
	8	Thick Black	DC 0V

## Cable: CN8

Wire Application	Wire	Color	Description	
Power	1	Red	DC 12V Output	
Security trigger signal	2	Purple	Security trigger si	gnal Output
Arming	3	Red White	Arming Output	WG mode: WG1 Output
Duress	4	Yellow White	Duress Output	WG mode: WG0 Output

Cable: CN9 CN111 Optional: (Request to purchase AR-725L485 additionally)

Wire Application	Wire	Color	Description
TTL Port	1	Black	DC 0V
	2	Yellow	ТХ
	3	White	TE
	4	Orange	RX
	5	Red	DC 5V
	6		





Enable "Share Door Relay" to open the same electronic lock regardless of whether it is triggered by the main controller or the Wiegand reader. This is achieved by using the NO contact of the blue-white wire in CN4, suitable for systems where the controller and the reader control the same lock. Disable "Share Door Relay" for card swiping on the main controller, triggering the NO contact of the blue-white wire in CN4. For card swiping on the Wiegand reader, triggering the NO contact of the blue-white wire in CN4. For card swiping on the Wiegand reader, triggering the NO contact of the blue-white wire bor Output in CN5 WG Port. This allows the main controller and the reader to independently control two electronic locks.

ROHS SOR FC CENINCC

V250108

Illuminated Touch-panel



Illuminated Touch-panel

## ROHS SOR FC CE NINCC

V250108

