

701Server XML Command Format

1. Set Controller Output State

```
<?xml version="1.0" encoding="utf-8"?> //fixed value of XLM head format//
<SoyalXML> // Head //
<Count>1</Count> // Total user command set //
<Command_0> // Command set number //
<CmdCode >1004</CmdCode > // Command Code (Please Reference JSON Command) //
<Area>0</Area> // Area Code //
<StartNode>1</StartNode> // Controller Node ID of this Area //
<StartPp>256</StartPp> // Controller IO Mapping Table //
<State>1</State> // 0: For Off 1:ForOn //
<Value>1</Value> // 0: For Latch(default) 1:For Pulse //
</Command_0 > // The last packet data no //
</SoyalXML> // End //
```